

Swiss Institute of Bioinformatics


INTRODUCTION

Cancer variant analysis

Geert van Geest

13.12.2024








Cancer is a disease of the genome

- >> Abnormal cell growth
- >> Potential to invade or spread
- Mostly initiated by acquired genomic mutations affecting genes regulating cell growth
- >>> Mutations occur by chance, but their rate can be affected by environmental factors
- Natural selection of malignant cells mutations build up








Variants – some definitions

- >> Variant: a difference between DNA
- >> Caused by a **mutation**: the process of a change in DNA
- >> Somatic variant: occurs only in a part of an organism
- >>> Germline variant: can be passed on the next generation
- >> Polymorphism: variant that is common in a population








Variant – an example

- >>> Mutation: the change in DNA that caused the petals to turn yellow
- >> Variant: the difference between the DNA in the yellow petals and the wild type














Types of mutations in cancer


- >> Small mutations (SNVs INDELs)
- Copy Number Variation (CNV)
 - Loss of heterozygosity (LOH)
- >> Structural variation
 - >> Fusion transcripts





Mutation detection - sequencing

- » Whole genome sequencing
- » Bait capture
 - >> Whole exome sequencing
 - >> Custom panels
- » Sequencing methods:
 - >> Short reads (Illumina, MGI, Element)
 - >> Long reads (PacBio, ONT)







questions on NGS




-

Bait capture

- RNA/DNA baits are designed for regions of interest
- >> Library prep as usual
- Capture with biotinylated baits

- (Much) lower sequencing and processing costs:
 - >> WES 100x: 25 M 2 x 100 bp
 - >> WGS 30x: 450 M 2 x 100 bp
- >> Not sequenced regions can contain valuable information, e.g. structural variation






9

Experimental design

- >> Tumor tissue is often not purely 'tumor'. It contains e.g. immune cells.
- >> How to discriminate between germline and somatic variation?
- >> Per patient two samples:
 - >> Tumor
 - >> Normal (e.g. blood)



Normal

Tumor





Downstream processing

- >> Adapter removal
 - >> e.g. fastp
- >> Alignment
 - >> bwa-mem or dragen
- >> Adding read groups
 - during alignment or e.g. samtools addreplacerg

- >>> Base quality score recalibration
 - >> GATK framework
- >> Deduplication
 - gatk MarkDuplicates
- >> Coverage/enrichment evaluation
 - e.g. mosdepth or gatk CollectHsMetrics





The sam/bam file format

- >> Usage: store alignments
- >> bam = compressed sam
- >> Important format to understand!

```
fasta
```


```
VN:1.6 SO:coordinate
      SN:chr6 LN:170805979
                 LN:83257441
      SN:chr17
      ID:bwa PN:bwa VN:0.7.17-r1188 CL:bwa mem ref genome.fa normal R1.fastq.gz normal R2.fastq.gz
      ID:samtools PN:samtools PP:bwa VN:1.21 CL:samtools sort
HWI-ST466:135068617:C1TD1ACXX:7:1114:9733:82689 163
                                                    chr6 60001 60
                                                                     100M =
                                                                                 60106 205
                                                                                           GATCTTATATAACTGTGAGATTAATCTCAGATAATGACACAA
CCCFFFFFHHHHHJJIJHIJJEIJUJJJJJJJJJJJJ NM:i:0 MD:Z:100 MC:Z:100M AS:i:100 XS:i:0
HWI-ST466:135068617:C1TD1ACXX:7:1303:2021:90688 99
                                                    chr6 60001 60
                                                                                            GATCTTATATAACTGTGAGATTAATCTCAGATAATGACACAA
@CCFFFFFGGHHIIFHGIEGHJJICEHIJJIIJJIEGHIIJJ NM:i:0 MD:Z:100 MC:Z:100 M AS:i:100 XS:i:0
HWI-ST466:135068617:C1TD1ACXX:7:2304:7514:30978 113
                                                    chr6 60001 60
                                                                     2S98M =
                                                                                 61252 1194 TAGATCTTATATAACTGTGAGATTAATCTCAGATAATGACAC
DEDDCEEFEEEFFFFFHHHHHHHIJJHIGJJJJIHHFGGJ NM:i:0 MD:Z:98 MC:Z:60S40M AS:i:98 XS:i:0
```





Marking duplicates

- Variant caller assumes each fragment is unique representation of the genome
- >> PCR/optical duplicates are not
- Marking PCR/optical duplicates improves variant calling accuracy
- Adding Unique Molecular Identifiers (UMI) strongly improves duplicate marking accuracy





Read groups

Have multiple groups of reads in a bam file

Add metadata to alignments:

- Samples
- >> Libraries
- Lanes
- **>>** ...

```
    @RG ID:rg1 LB:lib1 SM:sampleA
    @RG ID:rg2 LB:lib2 SM:sampleA
    read1 456345 chr20 RG:Z:rg1
    read2 456348 chr20 RG:Z:rg2
    read3 456357 chr20 RG:Z:rg2
    read4 456359 chr20 RG:Z:rg1
```






Small variants – different assumptions

- >> Small variants: SNVs and INDELs
- Germline variants have assumed variant allele frequencies:
 - >> 100% if homozogous alternative
 - >> 50% if heterozygous
- These do **not hold** for somatic variants

 heavily relies on tumor purity and
 heterogeneity
- Biased error strongly influences accuracy








Small variants - likelihood

Estimating likelihood and filtering can be based on:

- >> Sequencing error: base qualities and variant allele frequency
- >> Technical artifacts: 'panel of normals' information about expected non-random errors/artifacts
- >> Possibility of being a **germline variant**:
 - >> Germline call of normal sample
 - >> Databases of known germline variants, e.g. gnomAD








Small variants – GATK workflow

- >> Mutect2 haplotype aware variant calling
- >> FilterMutectCalls filtering variants based on:
 - >> Sequencing error
 - >> Technical artifacts
 - >> Germline variants








Small variants - haplotypes

- >> Haplotype: alleles in phase on the same chromosome
- >> Helps to detect sequencing error
- >> Germline: maximum 2 haplotypes
- >> Tumor: can have more than 2 hapltoypes





9

The VCF file format

```
##fileformat=VCFv4.3
##fileDate=20090805
##source=myImputationProgramV3.1
##reference=file:///seq/references/1000GenomesPilot-NCBI36.fasta
##contig=<ID=20,length=62435964,>
##INFO=<ID=NS,Number=1,Type=Integer,Description="Number of Samples With Data">
##INFO=<ID=DP,Number=1,Type=Integer,Description="Total Depth">
##INFO=<ID=AF,Number=A,Type=Float,Description="Allele Frequency">
##FILTER=<ID=q10,Description="Quality below 10">
##FILTER=<ID=s50,Description="Less than 50% of samples have data">
##FORMAT=<ID=GT,Number=1,Type=String,Description="Genotype">
##FORMAT=<ID=GQ,Number=1,Type=Integer,Description="Genotype Quality">
##FORMAT=<ID=DP,Number=1,Type=Integer,Description="Read Depth">
##FORMAT=<ID=HQ,Number=2,Type=Integer,Description="Haplotype Quality">
##FORMAT=<ID=HQ,Number=2,Type=Integer,Description="Haplotype Quality">
```


#CHROM	POS	ID	REF	ALT	QUAL	FILTER	INFO	FORMAT	NA00001	NA00002
20	14370	rs6054257	G	Α	29	PASS	NS=2;DP=9;AF=0.25	GT:GQ:DP:HQ	0 0:48:1:51,51	1 0:48:8:51,51
20	17330		Т	Α	3	q10	NS=2;DP=8;AF=0.25	GT:GQ:DP:HQ	0 0:49:3:58,50	0 1:3:5:65,3
20	1110696	rs6040355	Α	G,T	67	PASS	NS=2;DP=6;AF=0.5,0.5	GT:GQ:DP:HQ	1 2:21:6:23,27	2 1:2:0:18,2
20	1230237		Т		47	PASS	NS=2;DP=11	GT:GQ:DP:HQ	0 0:54:7:56,60	0 0:48:4:51,51
20	1234567	microsat1	GTC	G,GTCT	50	PASS	NS=2;DP=6	GT:GQ:DP	0/1:35:4	0/2:17:2








Question







- Large INDELs
- >> Translocations
- Inversions
- >> Tools: manta, tiddit
- If this causes a loss or multiplication: copy number variation (CNV)
- >> Translocations/inversions can lead to **gene fusions**





Gene fusion

- >> Fusion of ORF at the level of the genome
- Results in fused transcripts
- >> Can be estimated based on:
 - >> WGS
 - >> WES
 - >> RNA-seq
- >> Detection by discordant alignments


Translocation leading to fused ORFs




RNA-seq reads from fused transcripts



Reads aligned to reference genome







Time for exercises!



DATA SCIENTISTS FOR LIFE sib.swiss

